

# Dutro

COMPANY

## OFFSET OPERATION INSTRUCTIONS

1. Stand behind hand truck.
2. Rotate handle (A) counterclockwise.
3. Route strap (S) from its point of attachment (B), around the hook (C) and around the load.
4. From the load, run the strap around the hook (D) and around the hook (E) on the crank (Note that the end of the strap is toward the operator).
5. Pull out the slack; rotate the handle (A) clockwise to the left (Adjust the tension on the strap to allow the crank to turn and snap into locked position).

